

FIG. 1A

100

108

102

104

106

Print

Printer:

Name: Minolta #2

Status: Idle

Type: Minolta PageWorks/Pro 25

Where: min1

Comment:

Print to file: ☐

Properties

Page range:

☒ All

☐ Current page

☐ Selection

☐ Pages:

Enter page numbers and/or page ranges separated by commas. For example, 1,3,5-12

Copies:

Number of copies: 1

☒ Collate

Zoom:

Pages per sheet: 1 page

Scale to paper size: No Scaling

Print what: Document

Print: All pages in range

Options...

OK

Cancel

FIG. 1B




FIG. 2 is a block diagram of a system 200.




FIG. 2

FIG. 3

300




FIG. 4

400




FIG. 5

500




FIG. 6

600




FIG. 7

700




FIG. 8

800

Multiple Page-range Setting Printer Properties

Page Setup | Advanced | **Multiple Page-range Setting**

Set Total Page Number:
(Maximum is 999, 0 is to disable Multiple Page-range Setting function)
8

Set Page-ranges:
(Select a begin page # only for each page-range, the end # will be the next range begin # -1, the last end # is the total page number.)

1 (1-1)
2 (2-4)
5 (5-7)
8 (8-8) x Selected::

Simplex

Set Simplex / Duplex:

Printer Default ☐
Simplex ☒
Duplex ☐

Set Paper Source:

Printer Default
Manual Feeder
Envelop Tray
Tray 1
Tray 2
Tray 3
2000 Sheet Tray
5000 Sheet Tray
Fan Fold Paper Tray

Set Media Type:

Printer Default
Thin
75 g / m² (White)
Thick
Letterhead
Prepunched 3 holes
Recycle
Transparency
Light Red
Light Blue
Light Green

Paper Source Selected:
Tray 2

Media Type Selected:
75 g / m² (White)

NOTE

- The "Printer Default" is usually the default value for features. It is normally set on the printer's LCD.
- Set Page-ranges with ascending order.

Next range OK Cancel

408 320 322

FIG. 9A

TABLE 900

#	Page-range	Single/Duplex	Paper source	Media type	Etc.
1	1-1	S	Tray 2	75 g / m ² (White)	
2	2-4	D	Manual feeder	Recycle (Gray)	
3	5-7	S	Tray 3	Green	
4	8-8	S	Tray 2	75 g / m ² (White)	

FIG. 9B

TABLE 950

902 →

#	Page-range	Single/Duplex	Paper source	Media type	Etc.
1	1-2	D	Manual feeder	Green colored	
2	3-6	S	Tray 1	Thin	
3	7-20	S	Tray 3	Recycle	
4	21-22	D	Tray 2	Letterhead	
5	23-200	S	LCT	Thick	

FIG. 10




FIG. 11

